



## Firestone Formflash / Quickprime Repair Kit Instructions

1. Cut a patch that will extend at least 50mm on all sides beyond the area to be repaired and round off the corners. see fig 1
2. Lay the patch over the damaged area and mark around the perimeter. Use a piece of chalk. (not supplied)
3. Shake the primer well.
4. Apply a thin layer of the primer onto the area to be repaired, with paint brush or scrubber pad, and go about 10 – 15mm beyond the patch perimeter that you marked previously. see fig 2
5. Allow the primer to dry to tacky.
6. Remove the paper backing from the patch. See fig 3
7. Place the patch on the area to be repaired and apply lots of pressure to the whole surface area. See fig 4
8. Finally peel off the plastic backing. See fig 5 (Note, some Formflash is without the plastic backing)



fig 1



fig 2



fig 3



fig 4



fig 5